


LAMPIRAN 6

SISTEM STARTING AIR



Sumber: *Operation Manual Book*

Keterangan:

- | | |
|---|-------------------------------------|
| 1. Shut-off valve for starting air | AL: Starting air |
| 2. Non return valve | AZ: Starting air inlet |
| 3. Control valve and valve unit for start | EW: Vent and drain |
| 4. Safety valve | LE: Control air (board supply) |
| 5. Air bottle for control air supply unit | LF: Air spring air |
| 6. Control air supply unit | SL: Starting air inlet for stand-by |
| 7. Starting air valve | And safety control air |
| 8. Cylinder cover | |
| 9. Flame arrester | |
| 10. Automatic fine filter | |
| 11. Turning gear | |
| 12. Blocking valve on turning gear | |
| 13. Oil leakage return from air spring | |